

Configuring

Setting temperatures in “Manual” mode


Question:

Can I configure the temperature setting in Manual mode on MyChron5/5S?

Answer:

You can only configure this setting on MyChron5S.

To configure the temperature setting in manual mode, you have to access on the main menu of the device – System Setting – Temperature Setup.



Harness Type: indicate the extension of the sensors connected to the MyChron5S, it could be:

- **TC/TR** Thermocouple – Thermo-resistor
- **TR/TR** Thermo-resistor - Thermo-resistor
- **TC/TC** Thermocouple – Thermocouple

Temperature IN1/IN2: configure the two sensors inserting the correct labels.



Configuring

Please note: in case you configure the setting with the TC/TR wiring, we remind our users that it is mandatory to insert in the first input Exhaust Temp and in the second Water Temp, as shown in the image below:

